Function Switch / Switch disconnector

Mounting size

Current (A) 16 16

Power (kW) 3 5,50 5,50 5,50 0,55 1,50 2,50 3

3,70

4,50

7,50 10 13

0,75

2

3,70

5

25

4,50

Current (A)

2

2

2

2





## **KF16B**

Type Size: S1 Classification Contact: Rigid contact bridge **Classification Contact Mat: Silver Classification Terminal: Screw terminal** 

Sample image

AC-23A

AC-23A

AC-23A

AC-23A

gG

Max. Fuse rating IEC Fuse characteristic

UL60947-4-1, UL508 Rated insulation voltage Ui

IEC 60947-3	EN 60947-3, VI	DE 0660 Teil 107				
Rated insulation	voltage Ui					
			Voltage	e (V) AC / DC		
			•	690 AC		
Rated impulse w	vithstand voltage Uim	р				
Voltage (k)	V) Overvoltage cate	gory Pollution	degree Supply s	ystem		
	6 III	3	Valid for	lines with grounded common	neutral termination	
Pated uninterrun	oted current lu/lth			···· 3 ·····		
Current (A)		t temperature (°C)	Peak temperature (°C)	additional requirements		
16	7 1112/011	50	55	Ambient temperature +50°C	during 24 hours with peaks	s up to +55°C
Conventional en	closed thermal currer	nt Ithe		· · · · · · · · · · · · · · · · · · ·		
Current A (A)	Ambient temperature (°C)	Peak temperature (°C)	Additional requirements		No. of stages (from - to)	Mounting
16	35	40	Ambient temperature +35 peaks up to +40°C	°C during 24 hours with		
Rated operationa	al current le					
Utilization catego	ory			Voli	tage (V)	
AC-21A					20 - 690	
AC-22A				2	20 - 690	
Rated operationa			Valta na (10	No. of allowed	No	f mala a
Utilization catego AC-3	ory		Voltage (V) 220 - 240	No. of phases	NO. C	of poles
AC-3 AC-3			220 - 240 380 - 440	3		3
AC-3 AC-3			500 - 500	3		3
AC-3			660 - 690	3		3
AC-3			110 - 120	1		2
AC-3			220 - 240	1		2
AC-3			380 - 440	1		2
AC-3			500 - 500	1		2
AC-3			660 - 690	1		2
AC-23A			220 - 240	3		3
AC-23A			380 - 440	3		3
AC-23A			500 - 500	3		3
AC-23A			660 - 690	3		3
AC-23A			110 - 120	1		2

220 - 240

380 - 440

500 - 500

660 - 690

AC/DC

Voltage (V)

600 AC 1

1

1

1

No. of Fuses

1



## Datasheet KF16B

Rated thermal current		
Current (A)	Ambient temperature (°C)	Additional Text
16	0 - 40	-
General Information		

## Text

Warning! The opening of the branch-circuit protective device may be an indication that a fault current has been interrupted. To reduce the risk of fire or electric shock, current-carrying parts and other components of the controller should be examined and replaced if damaged. If burnout of the current element of an overload relay occurs, the complete overload relay must be replaced.
When intended for use as a motor disconnector the device shall be provided with a method of being locked in the OFF-position.

## GENERAL TECHNICAL INFORMATION

GENERAL TECHNICAL INFORMATION				
Tightening torque of screws				
	tightenir	ng torque (Nm)		tightening torque (Ib-in
		1,25		1
Rated short-time withstand current Icw				
		Time (s)		Current (A
		1		35
Size of conductor				
composition of conductor	Min. / Max. value	No. of conductor per terminal	Cross section (mm²) or (AWG/kcmil)	Material of the wire
Flexible wire	Max.	1	AWG 10	Copper
Flexible wire	Max.	1	4mm²	Copper
Flexible wire	Min.	1	AWG 18	Copper
Flexible wire	Min.	1	0.5mm²	Copper
Single-core or stranded wire	Max.	1	6mm²	Copper
Single-core or stranded wire	Max.	1	AWG 10	Copper
Single-core or stranded wire	Min.	1	AWG 18	Copper
Single-core or stranded wire	Min.	1	0.5mm <sup>2</sup>	Copper
Flexible wire with ferrule according to DIN 46228	Max.	1	4mm²	Copper
Flexible wire with ferrule according to DIN 46228	Min.	1	0.5mm²	Copper
Approbations				
Specification				Marking
CE marking				CE
JK Directives				
EC 60947-3; EN 60947-3; VDE 0660 Teil107				IEC 60947 EN 60947
UL 60947-4-1; CSA C22.2 No. 60947-4-1				c us LISTED77B7

Power loss per pole

		0,20
Conditions during transport and storing		
Minimum temperature (°C)	Maximum temperature (°C)	additional requirements
-40	85	In case of temperatures below -5°C no shock load permissible
General Information		
Text		

- Use only copper wires with or without tinned/silver-plated individual wires. Soldering the end of the wire before wiring is not allowed.

- Terminals with factory fitted jumper links are tightened during production for loss prevention. When opening the terminal clamps, make sure that no factory fitted links get lost and that all wire connections are properly seated.

- After wiring, ALL terminal screws must be tightened to the specified torque values.

- The protection class of the selected mounting type may vary if optional extras are used.

- Do not lubricate or treat contacts.

- Switches may only be mounted, connected and set into operation by qualified persons according to the accepted rules of technology.

Operating temperature

Min. Temperature [°C]	Max. Temperature [°C]
-5	55

Power (W)