



KF32

Type Size: S0

Classification Contact: Rigid contact bridge

Classification Contact Mat: Silver

Classification Terminal: Screw terminal

ated insulat	tion voi	tage UI		Voltage	e(V) AC/DC			
				-	690 AC			
ated impuls	e withs	stand voltage Uimp)					
Voltage	e (kV)	Overvoltage cate	gory Pollution	degree Supply s	ystem			Function
	6	III	3	Valid for	lines with grounded commo	on neutral termination		Switch / Switch disconnector
ated uninte	rrupted	current lu/Ith						
Current (A	,	Ambient	temperature (°C)	Peak temperature (°C)	additional requirements			
	2 I enclos	sed thermal curren	50 t Ithe	55	Ambient temperature +50°	°C during 24 hours with peal	ks up to +55°C	
Current (A)	Amb	ient temperature (°C)	Peak temperature (°C)	Additional requirements		No. of stages (from - to)	Mounting	Mounting size
32		35	40	Ambient temperature +35 peaks up to +40°C	°C during 24 hours with	-	-	
ated operat		urrent le						
tilization ca	tegory				Vo	oltage (V)		Current
C-21A						20 - 690		
C-22A						20 - 690	_	
ated operat tilization ca		ower		Voltage (V)	No. of phases	No	of poles	Power (k
0-3	legury			220 - 240	No. or phases	NO.	3	5 Fower (k
D-3 D-3				380 - 440	3		3	<u> </u>
C-3				500 - 500	3		3	
C-3				660 - 690	3		3	
C-3				110 - 120	1		2	1,
0-3				220 - 240	1		2	
C-3				380 - 440	1		2	5
C-3				500 - 500	1		2	7
C-3				660 - 690	1		2	8
C-23A				220 - 240	3		3	
C-23A				380 - 440	3		3	
C-23A				500 - 500	3		3	
C-23A				660 - 690	3		3	
C-23A				110 - 120	1		2	
C-23A				220 - 240	1		2	4
C-23A				380 - 440	1		2	7
C-23A				500 - 500	1		2	
C-23A				660 - 690	1		2	
ax. Fuse ra	ting IEC							
ise charact	eristic					No. of Fuses		Current
3						1		
L60947-	4-1.	UL508						

600 AC



Rated thermal current							
Current (A)	Ambient temperature (°C)	Additional Text					
30	0 - 40	_					
General Information							

- -Warning! The opening of the branch-circuit protective device may be an indication that a fault current has been interrupted. To reduce the risk of fire or electric shock, current-carrying parts and other components of the controller should be examined and replaced if damaged. If burnout of the current element of an overload relay occurs, the complete overload relay must be replaced.
- When intended for use as a motor disconnector the device shall be provided with a method of being locked in the OFF-position.

GENERAL TECHNICAL INFORMATION Tightening torque of screws tightening torque (Nm) tightening torque (lb-in) 1.25 11 Rated short-time withstand current lcw Time (s) Current (A) 350 Size of conductor Cross section (mm²) or (AWG/kcmil) composition of conductor Min. / Max. value No. of conductor per terminal Material of the wire Solid wire 0.5mm² Min Copper Flexible wire Мах AWG 10 Copper Flexible wire Max 4mm² Copper Flexible wire AWG 18 Min Copper Flexible wire 0.5mm² Min Copper Single-core or stranded wire Max Copper 6mm² Single-core or stranded wire Max AWG 10 Copper Single-core or stranded wire Min. AWG 18 Copper Flexible wire with ferrule according to DIN 46228 Min 0.75mm² Copper Flexible wire with ferrule according to DIN 46228 Max 4mm² Copper

Approbations	
Approbations Specification	Marking
CE marking	C€
UK Directives	

IEC 60947-3; EN 60947-3; VDE 0660 Teil107

IEC 60947-3 EN 60947-3

UL 60947-4-1; CSA C22.2 No. 60947-4-1



Power loss per pole

Power (W) 0,90

Conditions during transport and storing

Minimum temperature (*C)

-40

Maximum temperature (*C)

85

In case of temperatures below -5*C no shock load permissible

General Information

Text

- Use only copper wires with or without tinned/silver-plated individual wires. Soldering the end of the wire before wiring is not allowed.
- Terminals with factory fitted jumper links are tightened during production for loss prevention. When opening the terminal clamps, make sure that no factory fitted links get lost and that all wire connections are properly seated.
- After wiring, ALL terminal screws must be tightened to the specified torque values
- The protection class of the selected mounting type may vary if optional extras are used.
- Do not lubricate or treat contacts
- Switches may only be mounted, connected and set into operation by qualified persons according to the accepted rules of technology.

Operating temperature	
Min. Temperature [°C]	Max. Temperature [°C]
-	EE