

IEC 60047 2 EN 60047 2 VDE 0660 Tail 107

DH10-1R

Type Size: S0

Classification Contact: Rigid contact bridge

Classification Contact Mat: Gold

Classification Terminal: Screw terminal

Rated insulation voltage Ui				
		Voltage (V) AC / DC		
		690 AC		
Rated impulse withstand voltage Uimp Voltage (kV) Overvoltage category	Pollution degree	Cumply avetem		Function
Voltage (kV) Overvoltage category 6 III	3	Supply system Valid for lines with grounded common ne	outral termination	Switch
Rated uninterrupted current lu/lth	3	Valid for lines with grounded common ne	eutrai terriiiriation	Switch
Current (A) Ambient temperature	(°C) Peak tempera	ture (°C) additional requirements		
16	55	· · ·	uring 24 hours with peaks up to	+60°C
Rated operational current le			<u> </u>	
Jtilization category		Voltag	ne (V)	Current (
AC-15		220 - 240		
AC-15		380 - 440		
AC-21A		12 - 690		
Max. Fuse rating IEC				
Fuse characteristic			No. of Fuses	Current (
gG			1	•
GENERAL TECHNICAL INFORMATION				
Fightening torque of screws				
	tightenin	g torque (Nm)		tightening torque (lb-i
		0,60		
Rated short-time withstand current lcw		Time (s)		Current (
		1 1		Current (a
Size of conductor				
composition of conductor	Min. / Max. value	No. of conductor per terminal	Cross section (mm²) or (AWG/kcmil)	Material of the wire
Flexible wire	Max.	2	2.5mm²	Copper
Flexible wire	Max.	2	AWG 14	Copper
Single-core or stranded wire	Max.	2	AWG 12	Copper
Single-core or stranded wire	Max.	2	2.5mm²	Copper
lexible wire with ferrule according to DIN 46228	Max.	2	1.5mm²	Copper
Approbations				
Specification				Marking
CE marking				C€
JK Directives				
EC 60947-3; EN 60947-3; VDE 0660 Teil107				IEC 60947- EN 60947-
JL 60947-4-1; CSA C22.2 No. 60947-4-1				c % Lu
Power loss per pole	_			Power (\
conditions during transport and storing				1,;





General Information

Text

- Use only copper wires with or without tinned/silver-plated individual wires. Soldering the end of the wire before wiring is not allowed.
- Terminals with factory fitted jumper links are tightened during production for loss prevention. When opening the terminal clamps, make sure that no factory fitted links get lost and that all wire connections are properly seated.
- After wiring, ALL terminal screws must be tightened to the specified torque values.
- The protection class of the selected mounting type may vary if optional extras are used.
- Do not lubricate or treat contacts.
- Switches may only be mounted, connected and set into operation by qualified persons according to the accepted rules of technology.
- After installation of the switches the spacings between the terminals must be sufficient to fulfill the requirement of the applicable standards.

Operating temperature	
Min. Temperature [°C]	Max. Temperature [°C]
-25	60