



# **KF20B**

Type Size: S1 Classification Contact: Rigid contact bridge Classification Contact Mat: Silver Classification Terminal: Screw terminal

Sample image

## IEC 60947-3 EN 60947-3, VDE 0660 Teil 107

Rated insula	ation vol	ltage Ui						
				Voltage	(V) AC/DC			
					690 AC			
		stand voltage Uimp						
Voltag	ge (kV)	Overvoltage categ	ory Pollution	degree Supply s	ystem			Function
	6	III	3	Valid for	lines with grounded common	n neutral termination		Switch / Switch disconnector
Rated unint Current (		l current lu/lth	temperature (°C)	Peak temperature (°C)	additional requirements			
	20	Ampient	50	55	Ambient temperature +50°	C during 24 hours with pool	ke up to ±55°C	
		sed thermal current			Ambient temperature +50 t	c during 24 nours with pear	ks up to +55 C	
Current (A)		pient temperature (°C)	Peak temperature (°C)	Additional requirements		No. of stages (from - to)	Mounting	Mounting size
20		35	40	Ambient temperature +35° peaks up to +40°C	°C during 24 hours with	-	-	-
Rated opera	ational c	urrent le						
Utilization ca	ategory				Vo	ltage (V)		Current (A)
AC-21A						20 - 690		20
AC-22A						20 - 690		20
Rated opera	ational p	ower						
Utilization ca	ategory			Voltage (V)	No. of phases	No.	of poles	Power (kW)
AC-3				220 - 240	3		3	3,50
AC-3				380 - 440	3		3	6,50
AC-3				500 - 500	3		3	6,50
AC-3				660 - 690	3		3	5,50
AC-3				110 - 120	1		2	0,75
AC-3				220 - 240	1		2	2
AC-3				380 - 440	1		2	3,20
AC-3				500 - 500	1		2	4
AC-3				660 - 690	1		2	5
AC-23A				220 - 240	3		3	5,50
AC-23A				380 - 440	3		3	10
AC-23A				500 - 500	3		3	12
AC-23A				660 - 690	3		3	15
AC-23A				110 - 120	1		2	1,10
AC-23A				220 - 240	1		2	2,50
AC-23A				380 - 440	1		2	4,50
AC-23A				500 - 500	1		2	5,50
AC-23A				660 - 690	1		2	6
Max. Fuse r	ating IE	C						
Fuse charac	teristic					No. of Fuses		Current (A)
gG						1		35
UL60947	/-4-1,	UL508						
Rated insula	ation <u>vo</u> l	tage Ui						

Voltage (V) AC / DC 600 AC



## Datasheet KF20B

Rated thermal current		
Current (A)	Ambient temperature (°C)	Additional Text
20	0 - 40	-
General Information		

### Text

Warning! The opening of the branch-circuit protective device may be an indication that a fault current has been interrupted. To reduce the risk of fire or electric shock, current-carrying parts and other components of the controller should be examined and replaced if damaged. If burnout of the current element of an overload relay occurs, the complete overload relay must be replaced.
When intended for use as a motor disconnector the device shall be provided with a method of being locked in the OFF-position.

#### GENERAL TECHNICAL INFORMATION

	tightenin	g torque (Nm)		tightening torqu	ue (Ib-in)
		1,25			11
Rated short-time withstand current Icw					
		Time (s)		Cu	ırrent (A)
		1			350
Size of conductor					
composition of conductor	Min. / Max. value	No. of conductor per terminal	Cross section (mm²) or (AWG/kcmil)	Material of the wire	
Flexible wire	Max.	1	AWG 10	Copper	
Flexible wire	Max.	1	4mm <sup>2</sup>	Copper	
Flexible wire	Min.	1	AWG 18	Copper	
Flexible wire	Min.	1	0.5mm <sup>2</sup>	Copper	
Single-core or stranded wire	Max.	1	6mm²	Copper	
Single-core or stranded wire	Max.	1	AWG 10	Copper	
Single-core or stranded wire	Min.	1	AWG 18	Copper	
Single-core or stranded wire	Min.	1	0.5mm <sup>2</sup>	Copper	
Flexible wire with ferrule according to DIN 46228	Max.	1	4mm <sup>2</sup>	Copper	
Flexible wire with ferrule according to DIN 46228	Min.	1	0.5mm²	Copper	
Approbations					
Specification				Mari	king
CE marking				C	E
UK Directives					
IEC 60947-3; EN 60947-3; VDE 0660 Teil107				IEC 60 EN 60	
UL 60947-4-1; CSA C22.2 No. 60947-4-1				, <b>(</b> ),	DITE DITE

Power loss per pole

		0,30
Conditions during transport and storing		
Minimum temperature (°C)	Maximum temperature (°C)	additional requirements
-40	85	In case of temperatures below -5°C no shock load permissible
General Information		
Text		

- Use only copper wires with or without tinned/silver-plated individual wires. Soldering the end of the wire before wiring is not allowed.

- Terminals with factory fitted jumper links are tightened during production for loss prevention. When opening the terminal clamps, make sure that no factory fitted links get lost and that all wire connections are properly seated.

- After wiring, ALL terminal screws must be tightened to the specified torque values.

- The protection class of the selected mounting type may vary if optional extras are used.

- Do not lubricate or treat contacts.

- Switches may only be mounted, connected and set into operation by qualified persons according to the accepted rules of technology.

Operating temperature

Min. Temperature [°C]	Max. Temperature [°C]
-5	55

Power (W)