



KF25B

Type Size: S1 Classification Contact: Rigid contact bridge Classification Contact Mat: Silver Classification Terminal: Screw terminal

Sample image

IEC 60947-3 EN 60947-3, VDE 0660 Teil 107

Rated insula	ation vol	Itage Ui						
				Voltage	(V) AC/DC			
					690 AC			
		stand voltage Uimp						
Voltag	ge (kV)	Overvoltage categ	ory Pollution	degree Supply s	ystem			Function
	6		3	Valid for	lines with grounded commo	n neutral termination		Switch / Switch disconnector
		l current lu/lth	terme ereture (°C)	Deals temperature (°C)	additional requirements	_	_	
Current (Ambient	temperature (°C)	Peak temperature (°C)	additional requirements	O during O4 hours with nool	ke up te 1 EE°O	
	25 al analor	sed thermal current	50	55	Ambient temperature +50°	c during 24 hours with peak	ks up to +55 C	
Current (A)		pient temperature (°C)	Peak temperature (°C)	Additional requirements		No. of stages (from - to)	Mounting	Mounting size
25		35	40	Ambient temperature +35° peaks up to +40°C	C during 24 hours with	-		-
Rated opera	tional c	urrent le						
Utilization ca	ategory				Va	oltage (V)		Current (A)
AC-21A						20 - 690		25
AC-22A						20 - 690		25
Rated opera	tional p	ower						
Utilization ca	ategory			Voltage (V)	No. of phases	No.	of poles	Power (kW)
AC-3				220 - 240	3		3	4
AC-3				380 - 440	3		3	7,50
AC-3				500 - 500	3		3	7,50
AC-3				660 - 690	3		3	7,50
AC-3				110 - 120	1		2	1,10
AC-3				220 - 240	1		2	2,50
AC-3				380 - 440	1		2	5
AC-3				500 - 500	1		2	6
AC-3				660 - 690	1		2	7
AC-23A				220 - 240	3		3	7
AC-23A				380 - 440	3		3	12
AC-23A				500 - 500	3		3	15
AC-23A				660 - 690	3		3	17
AC-23A				110 - 120	1		2	1,50
AC-23A				220 - 240	1		2	3,30
AC-23A				380 - 440	1		2	5,50
AC-23A				500 - 500	1		2	7
AC-23A				660 - 690	1		2	7,50
Max. Fuse r		С						
Fuse charac	teristic					No. of Fuses		Current (A)
gG						1		35
UL60947	'-4-1,	UL508						
Rated insula	ation vol	ltage Ui						

Voltage (V) AC / DC 600 AC



Datasheet KF25B

Rated thermal current		
Current (A)	Ambient temperature (°C)	Additional Text
25	0 - 40	-
General Information		

Text

Warning! The opening of the branch-circuit protective device may be an indication that a fault current has been interrupted. To reduce the risk of fire or electric shock, current-carrying parts and other components of the controller should be examined and replaced if damaged. If burnout of the current element of an overload relay occurs, the complete overload relay must be replaced.
When intended for use as a motor disconnector the device shall be provided with a method of being locked in the OFF-position.

GENERAL TECHNICAL INFORMATION

	tightenin	g torque (Nm)		tightenin	g torque (Ib-in
	-	1,25		-	1
Rated short-time withstand current Icw					
		Time (s)			Current (A
		1			35
Size of conductor					
composition of conductor	Min. / Max. value	No. of conductor per terminal	Cross section (mm²) or (AWG/kcmil)	Material of the wire	
Flexible wire	Max.	1	AWG 10	Copper	
Flexible wire	Max.	1	4mm²	Copper	
Flexible wire	Min.	1	AWG 18	Copper	
Flexible wire	Min.	1	0.5mm ²	Copper	
Single-core or stranded wire	Max.	1	6mm²	Copper	
Single-core or stranded wire	Max.	1	AWG 10	Copper	
Single-core or stranded wire	Min.	1	AWG 18	Copper	
Single-core or stranded wire	Min.	1	0.5mm ²	Copper	
Flexible wire with ferrule according to DIN 46228	Max.	1	4mm²	Copper	
Flexible wire with ferrule according to DIN 46228	Min.	1	0.5mm²	Copper	
Approbations Specification					Marking
CE marking					((
-					CC
JK Directives					
EC 60947-3; EN 60947-3; VDE 0660 Teil107					C 60947- N 60947-
					~

Power loss per pole

		Power (W)
		0,50
Conditions during transport and storing		
Minimum temperature (°C)	Maximum temperature (°C)	additional requirements
-40	85	In case of temperatures below -5°C no shock load permissible
General Information		

Text

- Use only copper wires with or without tinned/silver-plated individual wires. Soldering the end of the wire before wiring is not allowed.

- Terminals with factory fitted jumper links are tightened during production for loss prevention. When opening the terminal clamps, make sure that no factory fitted links get lost and that all wire connections are properly seated.

- After wiring, ALL terminal screws must be tightened to the specified torque values.

- The protection class of the selected mounting type may vary if optional extras are used.

- Do not lubricate or treat contacts.

- Switches may only be mounted, connected and set into operation by qualified persons according to the accepted rules of technology.

Operating temperature

Min. Temperature [°C]	Max. Temperature [°C]
-5	55