

IEC 60047 2 EN 60047 2 VDE 0660 Tail 107

## **KG41**

Type Size: S0

Classification Contact: Rigid contact bridge

Classification Contact Mat: Silver

Classification Terminal: Screw terminal

IEC 60947-3 EN 60947-3, V	DE 0660 Teil 107			
Rated insulation voltage Ui				
		Voltage (V) AC / DC		
2		1000 DC with 3 or 4 contacts/p	ole in series	
Rated impulse withstand voltage Uir Voltage (kV) Overvoltage ca	·	Supply system		Function
8 III	3			Switch disconner
Rated uninterrupted current lu/lth				owiton dioconnic
	nt temperature (°C) Peak tempera	ature (°C) additional requirements		
40	50	55 Ambient temperature +50°C du	ring 24 hours with peaks up to	+55°C
UL60947-4-1 , UL508				
Size of conductor				
composition of conductor	Min. / Max. value	No. of conductor per terminal	Cross section (mm²) or (AWG/kcmil)	Material of the wire
Single-core or stranded wire	Min.	1	AWG 14	Copper
Single-core or stranded wire	Max.	1	AWG 8	Copper
General Information		_		
<sup>-</sup> Ext	photovoltaic applications, the devices shall be			
SENERAL TECHNICAL INFO	DRMATION			
ightening torque of screws				
	tighteni	ng torque (Nm)		tightening torque (i
		1,80		
Rated short-time withstand current	cw	Time (s)		Curren
		1		Curren
Size of conductor				
omposition of conductor	Min. / Max. value	No. of conductor per terminal	Cross section (mm²) or (AWG/kcmil)	Material of the wire
lexible wire	Max.	1	AWG 6	Copper
lexible wire	Max.	1	10mm²	Copper
ingle-core or stranded wire	Max.	1	AWG 6	Copper
ingle-core or stranded wire	Max.	1	16mm²	Copper
lexible wire with sleeve	Max.	1	10mm²	Copper
pprobations				
pecification				Marking
E marking				C€
K Directives				
EC 60947-3; EN 60947-3; VDE 0660	Teil107			IEC 6094 EN 6094
L 60947-4-1; CSA C22.2 No. 60947-	4-1			<b>17</b> 3
ower loss per pole				
				Powe





Conditions during transport and storing		
Minimum temperature (°C)	Maximum temperature (°C)	additional requirements
-40	85	In case of temperatures below -5°C no shock load permissible

## General Inform

## Text

- Use only copper wires with or without tinned/silver-plated individual wires. Soldering the end of the wire before wiring is not allowed.
- Terminals with factory fitted jumper links are tightened during production for loss prevention. When opening the terminal clamps, make sure that no factory fitted links get lost and that all wire connections are properly seated.
- After wiring, ALL terminal screws must be tightened to the specified torque values.
- The protection class of the selected mounting type may vary if optional extras are used.
- Do not lubricate or treat contacts.
- Switches may only be mounted, connected and set into operation by qualified persons according to the accepted rules of technology.
- After installation of the switches the spacings between the terminals must be sufficient to fulfill the requirement of the applicable standards.

	Operating temperature
Max. Temperature [°C]	Min. Temperature [°C]
55	-5